


# LT80S-TR-S20D

## MOTOR ACCESSORIES




|   |                  |                       |
|---|------------------|-----------------------|
| 1 | 80S70-RA-M-XXX   | Motor adapter armtype |
| 2 | 80S70-F-XXX      | Motor Flange          |
| 3 | 80S70-FL-XXX     | Motor adapter         |
| 4 | 80S70-SS-20-GS19 | Single shaft ø20      |
| 5 | 80S70-DS-20-GS19 | Double shaft ø20      |

All drawings can be downloaded from [www.almotion.nl](http://www.almotion.nl)

# LT80S-TR-S20D

## ACCESSORIES



|    |              |                            |
|----|--------------|----------------------------|
| 1  | 111-028-S    | Single Nut M6 with spring  |
| 2  | 172-713S     | Double Nut M6 L=40         |
| 3  | 80S121       | Clamping plate single      |
| 4  | 80S122       | Clamping plate double      |
| 5  | 8070-SH-XS-S | Bracket for Telem. Bracket |
| 6  | XSZB108      | Bracket for M8 sensor      |
| 7  | XS05B1PAL2   | M8 inductive sensor-cable  |
| 8  | XS508B1PAM8  | M8 inductive sensor-M8     |
| 9  | XSZB112      | Bracket for M12 sensor     |
| 10 | 8070-DB4-IN  | Sensor bracket             |
| 11 | 8070-SD-ME   | Switch bracket             |
| 12 | 8070-XCMD-B  | Bracket for switch         |
| 13 | XCMD2102L    | Switch with roll           |

All drawings can be downloaded from [www.almotion.nl](http://www.almotion.nl)